



INSTRUCTIONS FOR
PNEUMATIC PRESSURE BLEEDER KIT
MODEL NO: **VS0204.V5**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear eye protection



Wear protective gloves

1. SAFETY


- ✓ Keep this product in good working order and condition, take immediate action to repair or replace damaged parts.
- ✓ Use approved parts only. Unapproved parts may be dangerous and will invalidate the warranty.
- ✓ Keep children and unauthorised persons away from the work area.
- ✓ Keep work area clean and tidy and free from unrelated materials.
- ✓ Ensure the work area has adequate lighting.
- ✗ **DO NOT** use the kit to perform a task for which it is not designed.
- ✗ **DO NOT** allow untrained persons to use the kit.
- ✗ **DO NOT** use when tired or under the influence of drugs, alcohol or intoxicating medication.
- ✓ After use, clean equipment and store in a cool, dry, childproof area.
- ✓ Dispose of waste liquids in accordance with local authority regulations.
- ✓ Always read and comply with the warnings on the brake fluid container.
- ✓ Wear eye protection and keep skin contact to a minimum. If brake fluid enters eyes rinse with plenty of water and seek medical advice. If swallowed seek medical advice immediately.
- ❑ **WARNING!** Only use new Brake Fluid, used Brake Fluid or other fluids will contaminate the system and possible brake system failure may result.
- ❑ **WARNING! DO NOT** pollute the environment by allowing uncontrolled discharge of fluids.
- ❑ **WARNING!** Brake fluid is flammable - keep away from sources of ignition, including hot surfaces e.g. exhaust manifold.
- ❑ **WARNING!** Brake fluid will damage paintwork. Any spillage should be flushed with water immediately.
- ❑ **WARNING! DO NOT** allow the fluid capacity in the unit to fall below ½ litre during the bleeding process otherwise air may enter the system.

2. INTRODUCTION

One-man pressure brake and clutch bleeding system suitable for the professional workshop. Low pressure tank (20-40psi) can be pre-charged with compressed air - making the unit fully portable. Large reservoir means reduced risk of running the system dry during bleeding process or complete fluid change. Suitable for use on ABS systems. Features a long delivery hose for operation with a low level ramp and long reach handle for easy mobility. Supplied with a range of European, Japanese and US vehicle adaptors.

3. SPECIFICATION

Model No: VS0204.V4
Air Supply: 20-40psi
Air consumption: 4.5cfm
Inlet size: 1/4" BSP
Tank capacity: 5.0 litres
Hose Length: 3.7mtr




4. CONTENTS



Item	Part no.	Description	Applications	Internal dia.	Type
20	VS0204.V4-20	ADAPTOR CAP '1'	Chrysler, Jeep	43.5	Bayonet
21	VS0204.V4-21	ADAPTOR CAP '2'	Chrysler, Jeep (Blanking cap)	43.5	Bayonet
22	VS0204.V4-22	ADAPTOR CAP '3'	GM, Chevrolet, Hummer, Mazda	49.5	Bayonet
23	VS0204.V4-23	ADAPTOR CAP '3' 90° ELBOW	Ford Fiesta 2011 onwards	49.5	Bayonet
24	VS820SA	ADAPTOR CAP '6'	Most European manufacturers	42	Thread
25	VS0204.V4-25	ADAPTOR CAP '7'	Universal	N/A	Rubber cone 30-55mm
26	VS0204.V4-26	ADAPTOR CAP '8'	Universal	N/A	Rubber cone
27	VS0204.V4-27	ADAPTOR CAP '9'	Honda	56	Bayonet
28	VS0204.V4-28	ADAPTOR CAP '10'	Nissan	34.5	Bayonet
29	VS0204.V4-36	ADAPTOR CAP '41'	Ford Mondeo 2014 onwards, Ford Fiesta 2016 onwards, Mazda CX3/CX5	49.5	Bayonet
30	VS0204.V4-30	ADAPTOR CAP '19'	Chrysler, Hyundai, Mitsubishi, Nissan, Subaru	50.7	Bayonet
31	VS0204.V4-31	ADAPTOR CAP '21' 90° ELBOW	Toyota, Lexus	46.5	
32	VS0204.V4-32	ADAPTORS (c/w TUBES)			
33	VS0204.V4-33	CLAMP ASSEMBLY			
34	VS0204.V4-34	HOOK BOLT			
35	VS0204.V4-35	CHAIN			

5. AIR SUPPLY

- 5.1. Recommended hook up is shown in fig.2.
- 5.2. You will require an air pressure of 40psi and air flow according to specification.
- 5.3. Ensure that the air supply is clean and does not exceed 40psi. Too high a pressure and/or unclean air may damage the diaphragm and will shorten the product life due to excessive wear and may cause damage and/or personal injury.
- 5.4. Drain the air tank daily. Water in the air line will damage the unit and invalidate your warranty.
- 5.5. The minimum hose diameter should be 1/4" I.D and fittings must have the same internal dimensions.
- 5.6. Keep hose away from heat, oil and sharp edges. Check hoses for wear and make certain that all connections are secure.



6. OPERATION

6.1. Brake bleeding procedure.

6.1.1. Refer to the vehicle manufacturer's instructions for brake bleeding and wheel sequence before proceeding. If no specific instructions from the vehicle manufacturer exist, follow the instructions detailed below.

- ❑ **WARNING! Familiarise yourself with the hazards of brake fluid - read manufacturer's instructions on the container. DO NOT touch the vehicle's brake pedal whilst bleeding the brakes.**

6.1.2. Check that the pressure release valve (fig.3.1) is open and that there is no pressure within the unit. Unscrew the filler cap (fig.1.1) on the unit and top up to full capacity with new brake fluid. Replace filler cap and close the pressure release valve.

- ❑ **WARNING! Do not allow the fluid capacity within the unit to fall below ½ litre during the bleeding process otherwise air may enter the system.**

NOTE: The diaphragm may be visible from the neck of the filler and will require deflating before filling, this can be done by pushing down on the diaphragm with a clean blunt instrument.

6.1.3. Check that the air regulator (fig.3.2) is turned fully anticlockwise, the air intake valve (fig.3.3) and the fluid supply pipe valve (fig.1.3) are in the closed positions.

6.1.4. Connect the brake bleeder (fig.3.4) to a suitable compressed air supply.

6.1.5. Slowly open the air intake valve (fig.3.3) and turn the air regulator clockwise until a pressure of 20psi is registered on the pressure gauge (fig.1.2).

NOTE: The brake bleeder can be used remotely by closing the air supply valve once the unit has been charged with air and then disconnect the air supply.

- ✱ **DO NOT** exceed the maximum pressure of 40psi, if the unit exceeds this pressure the safety valve (fig.3.5) will be activated.

6.1.6. Connect one of the adaptors to the end of the fluid supply pipe and hold over a waste oil container, slowly open the valve (fig.1.3) to release air from the supply pipe. When brake fluid is free flowing, close the valve.

6.1.7. Remove the cap on the vehicle's brake fluid reservoir. If the brake fluid level is not at maximum, top it up and select a suitable adaptor for the vehicle. In some cases a universal adaptor will be required, see section 6.3. Tighten the adaptor onto the master cylinder ensuring that a good seal is achieved (fig.4).

6.1.8. Connect the fluid supply pipe quick connector to the adaptor and slowly open the valve (fig.1.3) to pressurise the system.

6.1.9. Starting with the brake furthest away from the master cylinder connect the tube from the bleeding bottle to the nipple and using a brake spanner open the nipple approximately ¼ turn (fig.5), brake fluid will flow through the clear pipe into the bottle, when there are no visible bubbles tighten the bleed nipple.

6.1.10. Repeat the process at each wheel in turn as necessary.

6.1.11. To remove the brake bleeder, shut off the fluid supply pipe valve (fig.1.3), close the air intake valve (fig.3.3) and open the pressure release valve to depressurize the unit.

6.1.12. Disconnect the fluid supply pipe from the adaptor, taking care not to spill any brake fluid and remove the adaptor from the brake fluid reservoir. Any excess fluid in the reservoir should be removed using the syringe and disposed of into a suitable waste oil container.

6.1.13. Refit the original brake fluid reservoir cap.

6.1.14. Changing the brake fluid.

6.1.15. Carry out the brake bleeding procedure as described above.

6.1.16. When new fluid can be seen in the clear tube tighten the brake nipple.



6.1.17. Repeat this procedure at each wheel in turn.

6.1.18. Disconnect as above (6.1.10 & 6.1.11).

NOTE: When brake bleeding and/or fluid changing is complete, test the action of the brake pedal to ensure that the brakes are working and are not spongy before using the vehicle on the road.


6.2. Clutch bleeding procedure.

6.2.1. Refer to the relevant vehicle manufacturer's instructions for clutch bleeding procedure. If no specific instructions from the vehicle manufacturer exist, the same procedures as for brake bleeding should be followed.



6.3. **Universal adapters.**

- 6.3.1. Universal adapters can be fitted to brake or clutch master cylinder fluid reservoirs using the universal adapter clamps, the two hook bolts and chains. Wrap the chain around the brake or clutch master cylinder and locate through the two holes in the adaptor and the two slots in the clamp, take out the slack in the chain using the nuts and then tighten the clamp to seal the adaptor to the master cylinder (fig.6).



7. MAINTENANCE

- 7.1. Ensure that the unit is depressurized before carrying out any maintenance and drain all fluids from the main tank and from the fluid supply tube.
- 7.2. Clean up any spilled brake fluid and wipe down with a clean cloth.
- 7.3. Store in a clean, dry and childproof location.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk