

Stock No.

**33171, 33172, 33178, 33180,
33182, 33192, 33203, 33210
08437**

To make assembly easier we recommend having two persons aid one another.

- Place the worktop on top of the cabinets.
- Align the pre- drilled holes in the worktop with the holes in the cabinets.
- Then secure with M6 X 16mm bolts.

