



Item	Part No.	Description
1	CPS01.01	LEG TUBE (TOP PART)
2	CPS01.02	LEG TUBE (CENTRE BOTTOM PART)
3	CPS01.03	LEG TUBE (CORNER BOTTOM PART)
4	CPS01.04	RAFTER TUBE
5	CPS01.05	HORIZONTAL TUBE
6	CPS01.06	BOTTOM CROSS RAILS
7	CPS01.07	3-WAY PEAK CONNECTOR
8	CPS01.08	4-WAY PEAK CONNECTOR
9	CPS01.09	3-WAY SIDE CONNECTOR - LEFT
10	CPS01.10	3-WAY SIDE CONNECTOR - RIGHT
11	CPS01.11	4-WAY SIDE CONNECTOR
12	CPS01.12	4-WAY COVER RAIL CLAMP
13	CPS01.13	ANGLED CORNER LEG
14	CPS01.14	3-WAY COVER RAIL CLAMP

Item	Part No.	Description
15	CPS01.15	15" ANCHOR
16	CPS01.16	FOOT PLATE
17	CPS01.17	CABLE CLAMPS
18	CPS01.18	CABLE (12" LENGTH)
--	CPS01.19	RETAINING PIN (NOT SHOWN)
--	CPS01.20	SPLIT PIN (NOT SHOWN)
--	CBN645.S	COACH BOLT M6x45mm (SINGLE) (NOT SHOWN)
--	FWM6.S	FLAT WASHER M6 SINGLE (NOT SHOWN)
--	NLN6.S	NYLOC NUT M6 ZINC DIN 985 (SINGLE) (NOT SHOWN)
--	CPS01.24	ROOF TARPULIN (NOT SHOWN)
--	CPS01.25	DOOR PANEL WITH ZIPPER (NOT SHOWN)
--	CPS01.26	BACK PANEL (NOT SHOWN)
27	CPS01.27	RATCHET HOOK

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.