



Issue: 1
Issue Date: 060313

ITEM	PART NO	DESCRIPTION
1	PSI800.01	SOCKET
2	PSI800.02	INDICATOR LIGHT
3	PSI800.03	SWITCH
4	PSI800.04	SCREW FOR PANEL
5	PSI800.05	FRONT PANEL
6	PSI800.06	LOWER PANEL
7	PSI800.07	UPPER PANEL
8	PSI800.08	SIDE COVER
9	PSI800.09	FAN
10	PSI800.10	FAN COVER
11	PSI800.11	SCREW
12	PSI800.12	SCREW
13	PSI800.13	TERMINAL (POSITIVE)
14	PSI800.14	TERMINAL (NEGATIVE)
15	PSI800.15	CIRCUIT BOARD

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.