



C.A 6418


GUIDE DE DÉMARRAGE RAPIDE (FR) / QUICK START GUIDE (GB) /
SCHNELLSTART-ANLEITUNG (DE) / GUIDA DI UTILIZZO RAPIDO (IT)/
GUÍA DE INICIO RÁPIDO (ES) / 快速使用手册 (CN)




/ 日期和时间




Calibrazione automatica / Calibración automática / 日期和时间



Mesure de terre / Earth measurement / Erdungswiderstandsmessung / Misura di terra / Medida de tierra / 接地电阻测量



Mesure de courant / Current measurement / Strommessungen / Misura di corrente / Medida de corriente / 电流测量



Notice de fonctionnement / User's manual / Bedienungsanleitung / Manuale d'uso / Manual de instrucciones / 用户手册

