



**153.160UK
LARGE ROTATING
DISCO BALL**

GENERAL SAFETY RECOMMENDATIONS:

- 1) Avoid direct eye exposure, especially applicable to persons with photo sensitive disorders - eg. Epilepsy.
- 2) For indoor use only. -
- 3) The capacitors inside the unit might be charged even if the unit is unplugged.
- 4) If the plug and/or mains lead are damaged, they need to be repaired by a qualified technician.
- 5) If the unit has not been used for a longer period of time, condensation can occur inside the housing. Please let the unit reach room temperature prior to use.
- 6) Keep out of the reach of children.

REPLACING THE BULB:

Turn the power off and allow the unit to cool
Hold the plastic sphere and turn it counter clockwise
Replace the bulb
Turn the sphere clock to secure it in to position
Turn the power on

SPECIFICATIONS:

Power supply 230Vac, 50Hz
5 colour rotating effect
Fixed mains lead with On/Off roack switch
Free Standing
All plastic construction