



Item	Part No.	Description
1	SGA4.V2-01	BODY
2	SGA4.V2-02	SCREW FOR KNOB
3	SGA4.V2-03	ADJUSTING SCREW
4	SGA4.V2-04	KNOB
5	SGA4.V2-05	HOUSING CAP
6	SGA4.V2-06	SPRING PLATE
7	SGA4.V2-07	SPRING (L.P)
8	SGA4.V2-08	SEAT HOLDER NUT
9	SGA4.V2-09	DIAPHRAGM PLATE
10	SGA4.V2-10	SLIP RING
11	SGA4.V2-11	DIAPHRAGM
12	SGA4.V2-12	SEAT HOLDER

Item	Part No.	Description
13	SGA4.V2-13	ENCAPSULATED SEAT
14	SGA4.V2-14	VALVE
15	SGA4.V2-15	SPRING HOLDER
16	SGA4.V2-16	SPRING (H.P)
17	SGA4.V2-17	VALVE PIN
18	SGA4.V2-18	OUTLET NIPPLE
19	SGA4.V2-19	INLET NUT
20	SGA4.V2-20	INLET STEM
21	SGA4.V2-21	FILTER
22	SGA4.V2-22	GAUGE (L.P)
23	SGA4.V2-23	GAUGE (H.P)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.