



Item	Part No.	Description
01A	CP108VRSBO.01A	Blade Bracket Assembly
2	CP108VRSBO.02	Quick Release Chuck Assembly
3	CP108VRSBO.03	Retaining Pin
4	CP108VRSBO.04	Torsion Spring
5	CP108VRSBO.05	Lock Button
6	CP108VRSBO.06	Motor Assembly
7	CP108VRSBO.07	Holder, Left Side
8	CP108VRSBO.08	Guide Rail
9	CP108VRSBO.09	Holder, Right Side
10	CP108VRSBO.10	Housing

Item	Part No.	Description
11	CP108VRSBO.11	Clip
12	CP108VRSBO.12	Self-Lock Button Spring
13	CP108VRSBO.13	Self-Lock Button
14	CP108VRSBO.14	Switch
15	CP108VRSBO.15	Battery Connection
17	CP108VRSBO.17	Battery Indicator
18	CP108VRSBO.18	Battery Indicator Cover
23	CP108VRSBO.23	Housing Screw
24	CP108VRSBO.24	Inductance

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.