

Fiber Optic Cleaning Card



1. Peel cover from unused "N."
2. For best results, apply a minimal amount of solvent from Fluke Networks Solvent Pen.

3. Place end-face perpendicular to card in first corner of unused "N."



4. Swipe through "N" shape using gentle pressure and moving from wet to dry.

5. Check end-face with microscope.

Do not swipe over the same space twice.

See our full range of fiber optic solutions at
www.flukenetworks.com

©2012 Fluke Corporation
Made in USA
6920 Seaway Blvd.
Everett, WA 98203 USA

Model Number FOC Cards (5pk) 7
Part Number 2799672



54082 05531 0
EAN 07 54082 05531 0